



1. Excavate hole as per recommended area and depth.
2. Ensure ducting is in place we recommend that a minimum of 150mm extrudes from ground level, if required this can be trimmed back once concrete is set.
3. Pour concrete ensuring that it is a mix of C35 to table 6 BS8110 and then tamp down well.
4. Push template and bolts into concrete and level accordingly.
5. When fitting the cabinet, remove the template and ensure that the concrete base is in complete contact with the underside of cabinet.
6. When the cabinet has been fitted, protect the studs with a suitable protective coating. Denzo tape or similar is recommended.
7. It is recommended that the cabinet is grouted internally to ensure water tight.

CUSTOMER QUADRANT SECURITY GROUP		MATERIAL: GALV SHEET	
DESCRIPTION: EQUIPMENT CABINET FOUNDATION 1000H X 1250W X 450D		DRAWING NUMBER: CTE150606JA	
DRAWN: Camera Tower Engineering Ltd 2005-2009		TREATMENT OR FINISH:	
			A4